

Instruction Manual

TEMPERATURE AND HUMIDITY CONTROLLER INSTRUCTION MANUAL

For TH330A / TH300A / AW-TH330A-W

Version 1.4 (Jun, 2021)

1. Overview

This plug-n-play temperature and humidity controller is designed for high relative humidity (>85%) and condensing environments, where slight temperature drop may cause condensation and could damage the sensor. This controller is equipped with one of the most robust humidity sensors on the market. This controller can control both temperature (heating OR cooling) and humidity (humidifying OR dehumidifying) at the same time, which is ideal for applications such as curing fridges.

2. Specifications

| | |
|----------------------------|--|
| Temperature Control Range | - 40°C ~ 80°C, - 40°F ~ 176°F |
| Temperature Resolution | 0.1°C (between -9.9°C ~ 80°C) 1°C (between -40°C ~ 10°C) 0.1°F (between -9.9°F ~ 99.9°F) 1°F (between -40°F ~ 10°F, 100°F ~176°F) |
| Temperature Accuracy | 0.5°C |
| Temperature Control Mode | On/Off Control. Heating or Cooling |
| Temperature Control Output | 15 A, 120 V or 240 V AC * |
| Humidity Control Range | 0 ~ 99.9% RH |
| Humidity Resolution | 0.1% RH |
| Humidity Accuracy | 3% RH |
| Humidity Control Mode | On/off control. Humidifying or dehumidifying |
| Humidity Control Output | 15 A, 120 V or 240 V AC * |
| Operating Temperature | 0°C ~ 50°C |
| Dimension | 91 x 140 x 46 mm |
| Input Power | 85 ~242 V AC, 50 Hz / 60 Hz |
| Sensor Cable Length | 6 ft (2 m) |
| Power Cable Length | 3 ft (1 m) |

** Please note: Although both temperature and humidity output can handle up to 15A, the combined total power of the two channels is limited to 15A due to the power cord's limitation.*

3. Front Panel




Figure 1. Front Panel.

Measured temperature window: In normal operating mode, this window shows measured temperature. In parameter setting mode, this window shows parameter name.

Measured humidity window: In normal operating mode, this window shows measured humidity. In parameter setting mode, this window shows parameter value.

Alarm indicator: When the alarm is muted, the alarm indicator (the small dot on the last digit) will be on.

SET key: Accesses the program settings and parameter settings.

UP key (Unmute): Increases the value. Press down momentarily to unmute the alarm.

DOWN key (Mute): Decreases the value. Press down momentarily to mute the alarm.

Temperature socket: Supplies power to heater/cooler.

Temperature indicator: Red LED indicator; it is on when the temperature socket is energized.

Humidity socket: Supply power to the humidifier/dehumidifier.

Humidity indicator: Green LED indicator; it is on when the humidity socket is energized.

WiFi indicator (AW-TH330A-W only): Blue indicator located on the right of the display shows the WiFi status of this controller.

Note: WiFi setup (for WiFi model only)

Please download latest AuberWiFi app from iOS Appstore or Android Google play and process the setup through the app. For support, please visit the Help Center, App with WiFi Setup, on auberins.com.

To reset the WiFi function of this controller, push down and hold SET key and down arrow key at same time for about 3s. Then WiFi indicator will blink fast (4 Hz). This indicates that this controller is waiting for new setup now. After the controller is setup to your phone successfully, the WiFi indicator will be solid ON at most of the time.

4. Getting Started

4.1 Power up the controller and connect the sensor

To power up the controller, simply plug its power plug to a wall outlet. Then connect the 4-pin connector from the humidity sensor to the sensor input port on the bottom of the controller. Please align the notch on the sensor plug with the key on the sensor socket. You can refer to the Section 6 in the manual for details.

4.2 Displayed Information

The top LED window displays the measured temperature, and the bottom LED window displays the relative humidity reading. If sensor is not connected or defective, the controller will show "Err" in its display window.

There is one LED indicator on each side of the controller to show the output status of each output socket. The red LED on the left is for the temperature-control socket, and the green LED on the right is for the humidity-control socket.

4.3 Decide the Control Mode for Each Output Socket

The temperature-control socket can be set to either drive a heating device or drive a cooling device. This temperature-control mode is determined by the parameter **tCM (tC n)**, which can be set to "HE" for heating, or "CL" for cooling.

Similarly, the humidity-control socket can be set to either drive a humidifying device or drive a dehumidifying device. This humidity-control mode is determined by the parameter **hCM (HC n)**, which can be set to "H" for humidifying, or "dEH" for dehumidifying.

The user should decide the appropriate configuration for each output socket based on the user's particular application. Please refer to section 4.5 and second 5 for details.

4.4 Change the Set Points

The set point for temperature is **TSP (tSP)**, and the set point for humidity is **HSP (HSP)**. To access the set points, simply short-press the SET key and then the top window will show **tSP** and the bottom window will show its value. Use UP or DOWN arrow keys to adjust the value, and short-press the SET key again to save the new value and go to the **HSP** setting. The way to adjust and save the setting is the same as for temperature set point. Once you press the SET key again, the controller will return to its normal operation mode. Please see Figure 2 for how to access the set points.




Figure 2. How to access set points.

4.5 Adjust Parameters

Other control parameters are grouped into three sub-menus: temperature (**tE**), humidity (**Hu**), and system (**SYS**)*. To access these parameters, long-press SET key for 3 seconds, the top window will show **EDT (Edt)**. Then use UP or DOWN arrow key to select the sub-menu item (**tE**, **Hu**, or **SYS**) in the bottom window, then press SET key again to confirm the selection. Please see Figure 3 for how to access these parameters. The details for each parameter are explained in section 5.




Figure 3. How to access parameter menus.

5. Parameter Settings

All parameters are listed in Table 1. When a parameter is displayed in the top window, its value is displayed in the bottom window. The user can use the UP or DOWN arrow key to adjust the value in the bottom window. Press the SET key to save the new value and go to the next parameter. If no key is pressed for 10 seconds, the controller will exit to its normal operating mode.

Table 1. Parameters.

| Code | Description | Setting Range | Initial | Note |
|------------------------------------|-------------|---|--|--------|
| Short-press SET Key | | | | |
| tSP | tSP | Temp. Set Point | -40°F ~ 176°F -40°C ~ 80°C | 75.0 1 |
| HSP | HSP | Humidity Set Point | 0 ~ 99.9% RH | 40.0 1 |
| Long-press SEK Key | | | | |
| Edt | Edt | Edit Parameters | tE: temperature menu Hu: humidity menu SYS*: system menu | tE 6 |
| Temp. control settings (tE) | | | | |
| C-F | C-F | Temp. Unit | C: Celsius F: Fahrenheit | F 7 |
| tCM | tC n | Temp. Control Mode | HE: heating mode CL: cooling mode | CL 1 |
| tdF | tdF | Temp. Control Differential | 0 ~ 50.0 | 3.0 1 |
| toF | toF | Temp. Calibration Offset | -10.0 ~ 10.0 | 0 2 |
| tAH | tRH | Temp. High Limit Alarm | -40°F ~ 176°F -40°C ~ 80°C | 95.0 3 |
| tAL | tRL | Temp. Low Limit Alarm | -40°F ~ 176°F -40°C ~ 80°C | 32.0 3 |
| tAS | tRS | Temp. Anti-short Cycle Delay (only for cooling) | 0 ~ 12 min | 0 4 |

| | | | | | |
|--|-----|--|--|-------|----|
| tSF | tSF | Temp. Sensor Failure Operation | ON: output energized OFF: output de-energized | OFF | 5 |
| Humidity control settings (H_U) | | | | | |
| HCM | HCM | Humidity Control Mode | dEH: dehumidifying H: humidifying | H | 1 |
| HdF | HdF | Humidity Control Differential | 0% ~ 50.0% | 3.0% | 1 |
| HoF | HoF | Humidity Calibration Offset | -10.0% ~ 10.0% | 0% | 2 |
| HAH | HAH | Humidity High Limit Alarm | 0% ~ 99.9% | 90.0% | 3 |
| HAL | HAL | Humidity Low Limit Alarm | 0% ~ 99.9% | 10.0% | |
| HAS | HAS | Humidity Anti-short Cycle Delay (only for dehumidifying) | 0 ~ 12 min | 0 | 4 |
| HSF | HSF | Humidity Sensor Failure Operation | ON: output energized OFF: output de-energized | OFF | 5 |
| HdM | HdM | Humidity Output Delay Mode | 0, 1, 2 | 0 | 8 |
| HdT | HdT | Humidity Delay Timer | 0 ~ 999 min | 5 | 9 |
| HoS | HoS | Humidity Operating Set Point | -40°F ~ 176°F | 36 | 10 |
| Hob | Hob | Humidity Operating Band | 0°F ~ 200°F | 2 | 10 |
| System setting (SYS)¹ | | | | | |
| PSD ¹ | PSD | Device Access Password | 100 ~ 999 | 100 | 11 |
| RST | RST | Factory Reset | N, Y | N | 12 |

Note 1: Only available for WIFI model AW-TH330A-W

Details about Each Parameter

Note 1. tSP and HSP are the set points for temperature-control and humidity-control respectively. tdF and HdF are the control-differential (i.e., control hysteresis band) to prevent the load being turned on and off frequently. These hysteresis bands are one-sided. tCM is the temperature control mode, which can be set to heating (HE) or cooling (CL). HCM is humidity control mode, which can be set to humidifying (H) or dehumidifying (dEH).

In the heating mode of the temperature-control channel, the controller will energize the output socket until the temperature rises to the set point tSP; the output socket will be energized again when the temperature drops below the set point (tSP - tdF). In contrast, in the cooling mode of the temperature-control channel, the controller will energize the output socket until the temperature drops to the set point tSP; the output socket will be energized again when the temperature rises above the set point (tSP + tdF). Please refer to the Figure 4 below when the output relay will be turned on.




Figure 4. Temperature output is decided by tSP and tdF.

Similarly, in the humidifying mode of the humidity-control channel, the controller will energize the output socket until the temperature rises to the set point HSP; the output socket will be energized again when the temperature drops below (HSP - HdF). In contrast, in the dehumidifying mode of the humidity-control channel, the controller will energize the output socket till the humidity drops to the set point HSP; the output socket will be energized again when the humidity rises above (HSP + HdF). Please refer to the Figure 5 below when the output relay will be turned on.




Figure 5. Humidity output is decided by HSP and HdF.

Small differentials give tight control. Large differentials reduce the frequency of cycle on and off, and it will extend the life of relay and compressor.

Note 2. toF and HoF are the sensor calibration offset for temperature and humidity readings respectively. The offset is used to set an input offset to compensate the error produced by the sensor or input signal itself.

For example, for temperature reading, if the unit displays 37°F when the actual temperature is 32°F, setting parameter toF = - 5 will make the controller display 32°F.

Note 3. The low limit alarm should be always lower than the high limit alarm. When the measured temperature is higher than tAH, the temperature high limit alarm will be on; when the measured temperature is lower than tAL, the temperature low limit alarm will be on.

Similarly, for humidity readings, when the measured humidity is higher than HAH, the humidity high limit alarm will be enabled; when the measured humidity is lower than HAL, the humidity low limit alarm will be enabled.

When the alarm is on, the display will be flashing between the measured value and the alarm type. To mute the alarm, press the DOWN key momentarily. When the alarm is muted, the alarm indicator (see Figure 1, the small dot on the last digit) will be lit. If the measured value gets out of the alarm zone and then back into the alarm zone again, the alarm will be on again. To resume the alarm, press the UP key, the alarm indicator should turn off.

To disable the alarm, set High Limit Alarm = Low Limit Alarm. For example, you can set both **tAH** and **tAL** to 32°F, so the temperature alarm will be disabled.

Note 4. The parameters **tAS** and **HAS** are Anti-Short Cycle Delays for cooling and dehumidifying respectively. The controller is used for cooling or dehumidifying control, and the load is a compressor. Use the parameter **tAS** or **HAS** to prevent the compressor being turned on again when it is at high pressure (i.e., just after it is turned off). Otherwise, it may shorten the life of compressor. The Anti-Short Cycle Delay function is used to prevent the rapid cycling of the compressor. It establishes the minimum time that the output contact remains open (after reaching cutout) before closing again. The delay overrides any load demand and does not allow the output contact to close until the set time-delay value has elapsed. It gives time to release the refrigerant pressure through evaporator. It is typically set to 4 - 6 minutes.

Note 5. Parameters **tSF** and **HSF** are the Sensor Failure Operation for temperature and humidity control respectively; they can be set to ON or OFF. When it is set to ON, the output will always be on when the sensor fails; when it is set to OFF, the output will always be off when the sensor fails.

For example, when the unit controls a refrigerator for food, you may want to set the **tSF** to ON if the sensor fails to keep the food cold. When it controls a heater, you may want to set the **tSF** to OFF for safety purpose.

Note 6. **EDT** is the menu-editing parameter. Select **tE** menu for temperature control settings; select **Hu** menu is for humidity control settings, and select **SYS** is for system settings.

Note 7. **C-F** is the parameter to set the temperature unit: **C** is for Celsius, and **F** is for Fahrenheit.

Note 8. The parameter **HdM** sets the mode for delaying or constraint the humidity output. It has three available modes, which are listed and explained in the table below.

Table 2. Humidity output delay mode.

| HdM | Mode | Details |
|-----|-------------------|--|
| 0 | No delay | Default value. No delay or constraint on the humidity output. |
| 1 | Time-delay | Delay the humidity output by a timer set by HdT . |
| 2 | Temperature-range | Allow humidity output only when the temperature is within a range defined by parameter HoS and HoD . |

In situations such as controlling a curing chamber converted from a fridge, there is usually a big decrease in the relative humidity (RH%) whenever the compressor of the fridge is working. Also, there may be significant increase in the relative humidity when the user opens the door of the fridge. This kind of change in RH% can gradually recover. However, if the controller's humidity control kicks in right away, it creates in a big swing in the RH%.

Using time-delay (**HdM** = 1) or temperature-range constraint (**HdM** = 2) can help users to reduce the RH% swing.

Note 9. The parameter **HdT** sets the delay timer for humidity output; it can be set from 0 to 999 minutes. When **HdM** is set to "1", the output to the humidity control will be delayed for a time period set by **HdT**.

Please note, the **HdT** is effective in both humidifying and dehumidifying mode. In dehumidifying mode, the actual delay time of the humidity output is decided either by either **HAS** or **HdF**, whichever is longer.

Note 10. The parameters **HoS** and **Hob** set up a temperature range within which the humidity output is enabled. **HoS** defines a temperature set point for enabling humidity output, i.e., a lower boundary; and **Hob** defines the temperature band. Please see the diagram in Figure 6 for how these two parameters affect the humidity output.

For example, when **HdM** = 2, **HoS** = 36°F, and **HoB** = 2°F, that means when the temperature is below 36°F or above 38°F the humidity output won't be activated, even when the controller calls for output to the humidity channel.




Figure 6. When the humidity output delay mode is **HdM** = 2, the humidity output is allowed only when the temperature is within the range set by **HoS** and **HoD**.

Note 11. **PSD** is the Device Access Password (only available to WIFI models). This parameter is used to lock the parameter settings on the AuberWIFI app.

Note 12. **RST** is the reset parameter. Choose "n" to take no action. Chose "y" to reset all parameters back to factory settings.

6. How to install the sensor to the unit.


The connector of sensor contains a slot for fitting pin connection. It locates at the bottom of the controller. It also has a spring lock to prevent disconnections from accidental pulling on the cable.

To install the sensor to the controller: 1) Identify the key on the male sensor connector (Figure 7, a) and the notch on the female connector (Figure 7, b). 2) Hold the tail of the female connector, align the notch and the key, and push the female connector forward.

To remove the connector, hold the spring-loaded collar on the female connector and pull it back. Please see Figure 8.



(a)



(b)



(c)

Figure 7. Install the sensor.




Figure 8. Remove the sensor.

Auber Instruments

5755 North Point Parkway, Suite 99

Alpharetta, GA 30022, USA

www.auberins.com

info@auberins.com

Copyright © 2021 Auber Instruments Inc. All rights reserved.
 No part of this datasheet shall be copied, reproduced, or transmitted in any way without the prior, written consent of Auber Instruments. Auber Instruments retains the exclusive rights to all information included in this document.